

NATURAL ACTION WATER - SHOWER UNIT

STEP BY STEP INSTRUCTIONS

IMPORTANT

All the illustrations in this instruction show typical plumbing methods; actual installations must be adapted to individual requirements and regional codes. The author has made every effort to ensure accuracy and reliability of the information, instructions, and directions. However, neither the author nor the manufacture will accept responsibility for misinterpretation of the directions or human error.

NOTE:

1. This device is not designed for extended hot water use above 140 degrees.
2. This device is not designed to sustain freezing temperatures with residue water inside; function will possibly be deteriorated.
3. ***Do not drop - function may be deteriorated.***
4. The unit you received may rattle, this is normal; it contains a geometrically tuned chamber with specific geometric forms that align with the direction of flow.
5. The unit is bi-directional.
6. Will become brittle and may deteriorate desired function if left exposed to the sun for an extended period of time.

INSTALLATION INSTRUCTIONS:

7. Remove shower disperser head.
8. Install removed shower disperser head on to the units ½ inch male pipe threaded end. Some choose to leave this dispenser off if you are going to fill water containers
9. Install the shower unit to ½ inch shower arm pipe where shower disperser head was originally removed from. Be aware of possible cross threading, unit should start on threads easily when it is lined up.
10. If shower head is too low it may be necessary to purchase an extension shower arm or adjustable shower adapter.
11. If a 10 inch riser shower arm is used, remove the existing shower arm and install the 10 inch riser in its place and follow the same procedures installing the Structured Water Unit between the adapter and the shower disperser head.